

## **BEFORE TILING:**

- 1. Make sure you sweep your floors prior to tiling
- 2. Prime the walls & floors with Ardex "Multi Prime" and silicone joints where walls and floors meet

## **BEGIN TILING:**

- Measure out your floor plan (we recommend to begin walls before floors)
- 2. We suggest measuring your doorway first, this will ensure even cuts going down your passage way
- 3. Use a 10mm 15mm trowel for your floors. We recommend tiles under 500mm to use a 10mm trowel. For 600x600mm tiles we recommend using 15mm trowels. Speak to one of our trades assistants to work out what is most suitable for your tiles
- 4. Mix Ardex "Bondmastic" with water to the required measurement (on the back of the bag)





- 5. Leave to sit for approximately 5 minutes
- 6. Remix the glue so the product can begin reacting
- 7. Use ralmondi clips (while tiling) to give you a nice flat surface
- 8. Any excess glue coming through the tiles wash the joint with a brush and sponge
- 9. Once this is completed, you then begin silicone and grouting after 12 hours (next day)

## **GROUT & SILICONE FINISHING PRODUCT:**

- 1. Grout all the tiles on the wall and floor (but do not grout the corners where the walls & floors meet this is done with silicone)
- 2. Wash off with damp sponge to remove excess grout off the tiles
- 3. Cut Ardex silicone at a 45 degree angle and squeeze silicone out slowly into the joint of the walls & floor
- 4. Once complete use Ardex "SG SPRAY" and spray onto the silicone and use a silicone adapter to give you a smooth finish
- 5. Grout will leave a residue so polish it off with a rag once it is dry



## **TIPS**

- When finish cleaning the silicone off then put a bit of smooth fix on your finger and run slowly off the silicone – this helps to give a smoother finish
- If there is a laundry adjacent to the bathroom (on the same wall) this wall will also need to be waterproof to prevent water leaking through

**BATHROOM WATERPROOFING VIDEO-**

https://youtu.be/ADp7BM-awlY

**BATHROOM TILING VIDEO-**

https://youtu.be/pe6WU-4AwPw









**Ardex "Multi Prime"** 



Ardex "ST"



Ardex "WPM 155"





Ardex "SG Spray"



**6mm Trowel** 



**Raimondi Clips** 

